

BLT 250 PNEUMATIC LINE THROWER



The BLT 250 pneumatic line thrower is an advanced system which throws projectiles using the power of compressed air. Therefore it can be air-transferred as a simple cargo.

It has one main body (launcher) & four easily reloaded projectiles, it meets the demands of **SOLAS / IMO regulation 74 / 83** and is approved by **RINA**.


With regular maintenance the shelf life is unlimited!



ASSEMBLY AND LAUNCHING OF THE BLT 250




1. Screw the launching tube on the throwing chamber.



2. Reach the orange line inside the launching tube.



3. Open the yellow valve, you will hear the air flow in the chamber. Count 15secs & shut the valve. The air flow has stopped.



4. Attach the orange line to the white line of the projectile.



5. Insert the projectile inside the launching tube.



6. Place the BLT 250 in a shooting angle of 30-45 degrees from the ground.



7. Aim for target, press and hold the yellow safety button.



8. Press the trigger and shoot!